



TUNEUP PROCEDURE – PHASE-LOCKED SOURCES AND OSCILLATORS

INTRODUCTION

■ These instructions cover the crystal installation and alignment procedures for Frequency West crystal controlled phase locked sources and oscillators. The procedures cover the various equipment models and are organized by sections listed below. The user should perform only those procedural steps that apply to his own equipment.

Section

Equipment

Crystal Installation

Sources without Ovens

Equipment model numbers ending in: X, XA, XB

Sources with Ovens

Equipment model numbers ending in: XO and XC

Alignment Procedures

Preliminary Setup – Sources Using External Reference Oscillator

Equipment model numbers ending in: XE

Alignment – All Phase Locked Sources and Oscillators

All equipment




Figure 1

(408)-249-2850 TWX (910)-338-0163

